

BMW R1200/R1250GSA Top Case Mounting Plate Installation Instructions





Installation instructions:
BMW R1200/1250 GSA
Top Case Mounting Plate
to OEM BMW Top Rack



Fitting kit includes:

- 1 - Rear clamp
- 4 - 6mm x 12mm cap screws
- 4 - 6mm Nyloc nuts
- 2 - Front clamps
- 4 - 5mm x 12mm cap screws

1. Position the two front clamps and single rear clamp onto the OEM BMW rail as per below image.



2. Position the Bumot Top Case Mounting Plate with the four rear 6mm cap screws and four nyloc nuts. Leave these four cap screws loose, do not tighten the nyloc nuts fully just yet.
3. Install the four front 5mm cap screws with Loctite 243. Leave these four cap screws loose, do not tighten them just yet.
4. Tighten the four rear 6mm cap screws with nyloc nuts and then tighten the four front 5mm cap screws.

