BMW R1200GS Pannier Rack Installation Instructions





www.adventurebikeshop.com.au



INSTALLATION INSTRUCTIONS BMW 1200GS

Thank you for purchasing Bumot Luggage Systems for your motorcycle. This luggage, handcrafted in Bulgaria, is designed for the rider who demands the most durable and functional luggage for their adventure touring. Bumot Luggage has built in several features, including hinged lids and strap attachment points, to name a couple. Powder coating, inside & out, provides a durable finish for your luggage system. We're confident you will enjoy your new luggage system for years to come.

General Instructions:

Please read through these instructions completely before starting installation. Do not tighten any bolt until the entire assembly is completed. Leave all bolts completely loose until every component is in place. Once everything has been installed, tighten all bolts snugly. After the complete system has been snugly bolted down, and any adjustments made, remove one bolt at a time. Using blue Loc-Tite © reinstall and fully tighten each bolt. NOTE: Do not apply Loc-Tite © to any bolt which has is a self-locking nut.

1. If equipped, remove the original BMW luggage rack.







2. Attach the left pannier rack to the frame with M6x40 bolt and 22mm aluminium spacer.



3. Now attach the pannier rack under the rear frame with M5X35 bolt and 6 mm spacer. Be carefull not to cross thread the screws.



4. Attach the pannier racks using the largeclamps with M8X45 and thesmall clamps below, with M5X35 to the frame.







5. Now install the right side pannier frame.Install the connecting bar with M6X20 bolts





6. Tighten all bolts.



ENJOY YOUR NEW BUMOT SYSTEM !!!

BUMOT Luggage System

Ph:+359 887 649 709 <u>www.bumot.eu</u> <u>info@bumot.eu</u>