





Installation Instructions – Triumph Tiger 800/XC

Thank you for purchasing a BUMOT luggage system for your motorcycle. BUMOT luggage is handcrafted in Bulgaria and is designed for the rider who demands the most durable and functional luggage for their adventure touring. We're confident you will enjoy your new luggage system for years to come.

Please read through these instructions completely before starting installation. Leave all hardware loose until all components are in place and initial assembly is completed. Once everything has been installed, tighten all bolts snugly. Do not apply liquid threadlock (LocTite or similar) to any bolt which has a self-locking nut.

Installation Hardware Contents -

- mf M8 x 70mm Bolt Qty 4
- mf M8 Washer Qty 8
- mf M8 Self-Locking Nut Qty 4
- If 12 mm Spacer Qty 4
- mf Clamp Qty 2
- mf M5 x 35mm Bolts Qty 4
- of M5 Washer Qty 4
- *mf* M6 x 25mm Bolt − Qty 2
- of M6 Washer Qty 4

Instructions -

1. Remove the passenger seat, four bolts and plastic cover on the tail section.



2. Remove the right and left side factory luggage support (if equipped).





3. Attach the right side pannier rack to the frame with the included M8 x 70mm bolts, M8 washers, 12mm spacers and M8 self-locking nuts in the upper two points of attachment.





4. Install the clamp around the passenger peg frame tube and attach using two M5 x 35mm bolts and two M5 washers.



- 5. Repeat steps 3 and 4 to install left side pannier rack.
- 6. Install the rear connecting bar with supplied M6 x 25mm bolts, M6 washers, and M6 self-locking nuts as shown below.



7. Tighten all mounting hardware securely and recheck after first 30 kilometers of use.

Enjoy your new BUMOT luggage system!

BUMOT Motorcycle Luggage Ph:+359 887 649 709 www.bumot.eu info@bumot.eu