

Yamaha XT1200Z

Super Tenere Pannier Rack Installation Instructions





Installation Instructions – XT1200Z Super Tenere Pannier Rack

Thank you for purchasing a BUMOT luggage system for your motorcycle. BUMOT luggage is handcrafted in Bulgaria and is designed for the rider who demands the most durable and functional luggage for their adventure touring. We're confident you will enjoy your new luggage system for years to come.

Please read through these instructions completely before starting installation. Leave all hardware loose until all components are in place and initial assembly is completed. Once everything has been installed, tighten all bolts snugly. Do not apply liquid threadlock (Loctite or similar) to any bolt which has a self-locking nut.

Installation Hardware Contents -

-  M10-1.25 x 80mm Bolts – Qty 4
-  M10 Washer – Qty 4
-  M8 x 40mm Bolt – Qty 1
-  M8 Washer – Qty 1
-  M8 Self-Locking Nut – Qty 1
-  M6 x 25mm Bolts – Qty 2
-  M6 Washers – Qty 4
-  M6 Self-Locking Nuts – Qty 2
-  28mm Spacer – Qty 2
-  15.5mm Spacer – Qty 2

Instructions -

1. Remove the two bolts and spacers from the factory Yamaha pannier mounts (if equipped) and remove the mount. Do the same on the opposite side. Retain the original factory washers as they will be reused.



2. Remove the right side factory Yamaha pillion peg luggage support (if equipped) from the pillion peg bracket. Remove the two mounting screws and the pillion peg mounting bracket.



3. Remove the left side factory Yamaha pillion peg luggage support (if equipped) from the pillion peg bracket.



4. Attach the right side pannier rack to the frame with the included M10 x 80mm bolt, M10 washer, and 28mm spacer in the rear mounting point. Use the included M10 x 80mm bolt, M10 washer, and 15.5mm spacer in the front mounting point. Both spacers should be placed on top of the original Yamaha mount washer and behind the pannier rack mount. See picture below for hardware order.



5. Install the pillion peg bracket over the BUMOT rack mount. Reinstall using the original bolts.



6. Attach the left side pannier rack to the frame with the included M10 x 80mm bolt, M10 washer, and 28mm spacer in the rear mounting point. Use the included M10 x 80mm bolt and 15.5mm spacer in the front mounting point. Install order of hardware is the same as the right side rack in Step 4.
7. Using the hole where the original Yamaha pillion peg luggage support was installed (if equipped), attach the left side forward rack mount with a M8 x 40mm bolt, M8 washer, and M8 self-locking nut.
8. Install rear connecting bar with supplied M6 x 25mm bolts, M6 washers, and M6 self-locking nuts as shown below.



Enjoy your new BUMOT luggage system!

BUMOT Motorcycle Luggage
Ph:+359 887 649 709
www.bumot.eu
info@bumot.eu