

KTM 1190/1290 Pannier Rack Installation Instructions





Installation Instructions – 1190 Adventure Pannier Rack

Thank you for purchasing a BUMOT luggage system for your motorcycle. BUMOT luggage is handcrafted in Bulgaria and designed for the rider who demands the most durable and functional luggage for their adventure touring. We're confident you will enjoy your new luggage system for years to come.

Please read through these instructions completely before starting installation. Leave all hardware loose until all components are in place and initial assembly is completed. Once everything has been installed, tighten all bolts snugly. Do not apply liquid threadlock (Loctite or similar) to any bolt which has a self-locking nut.

Installation Hardware Contents -

-  M8 x 20mm Bolt – Qty 2
-  M8 x 70mm Bolt – Qty 1
-  M8 x 50mm Bolt – Qty 2
-  M8 x 35mm Bolt – Qty 1
-  M8 Washers – Qty 6
-  M6 x 20mm Bolt – Qty 2
-  M6 Self-Locking Nuts – Qty 2
-  M6 Washers – Qty 4
-  22mm Aluminum Spacers – Qty 2

Instructions -

1. Remove the five bolts and spacers from the factory KTM luggage mount. Remove the factory mount assembly. Do the same on the opposite side.



2. Install the left side pannier rack to the frame by starting with the lower mounting bracket. In the mounting hole at the front of the lower bracket, use a M8 x 35mm bolt, a M8 washer, and the original aluminum spacer. In the mounting hole at the rear of the lower bracket, use a M8 x 50mm bolt, a M8 washer, and the included 22mm aluminum spacer. The smaller diameter of the included spacer should be on the bike side. See picture below for detail.



3. Install the upper mounting point of the left side rack with a M8 x 20mm bolt and M8 washer.



4. Install the right side pannier rack to the frame by starting with the lower mounting bracket. In the mounting hole at the front of the lower bracket, use a M8 x 50mm bolt, a M8 washer, and the original aluminum spacer. In the mounting hole at the rear of the lower bracket, use a M8 x 70mm bolt, a M8 washer, and the included 22mm aluminum spacer. The smaller diameter of the included spacer should be on the bike side.

5. Install the upper mounting point of the right side rack with a M8 x 20mm bolt and M8 washer.
6. Install the rear crossbar with the supplier M6 x 20mm bolts, M6 washers, and M6 self-locking nuts, as shown below.



Enjoy your new BUMOT luggage system!

BUMOT Motorcycle Luggage
Phone: +359 887 649 709
www.bumot.eu
info@bumot.eu